

HydraMax[®] Home

Installation Guide

1-Bucket



THANK YOU!


Welcome to the world of hydroponics with the HydraMax Recirculated Deep Water Culture System (RDWC)! We are thrilled to have you as part of our hydroponic community and would like to express our sincere gratitude for choosing the HydraMax system. Assembling your RDWC system is a breeze, designed with simplicity and efficiency at its core. Our comprehensive instructions and user-friendly design ensure a quick and hassle-free setup process. Get ready to unlock the full potential of your plants as they thrive in the oxygen-rich, nutrient-dense environment created by the HydraMax RDWC. Experience the wonders of hydroponics like never before!




Before you begin...

To ensure a smooth assembly process, there are a couple items you'll need. Firstly, make sure you have some teflon tape on hand to secure the pump adapter fittings effectively. This tape will provide a reliable seal, preventing any potential leaks. Additionally, having a pair of adjustable pliers will come in handy for securely tightening the threaded fittings. These pliers allow you to achieve a snug fit, ensuring the components are firmly connected.

System at a Glance


System at a Glance





Bucket Assembly


Bucket Assembly



Insert the drain fitting with gasket from inside the bucket and tighten the nut below.



Insert each leg into the bucket and then press or tap the bucket onto a level surface to ensure that each leg is fully seated.



Final Assembly

Final Assembly




Remember to slide a spring clamp onto the hose before pushing the hose over the barb. Then, slide the spring clamp over the barb.

Lower the circulator into the the bucket, mating the bracket to the recessed lip in the corner.



Attach the Qwik-Lok hose to the drain fitting and slide the locking ring into the locked position. Attach the other end of the hose to the pump as shown.




Qwik-Lok Operation


Qwik-Lok Operation



To connect a Qwik-Lok hose, with the blue ring in the “latched” position, simply push the hose onto the fitting.



Once connected, slide the blue ring to the “locked” position.



To disconnect, hold the blue ring with two fingers and pull the hose off of the fitting in one motion.

Adding a Chiller

Assembly Diagram



If your HydraMax Home, 1-Bucket System is Chiller compatible. Connect the chiller between the pump and the circulator with the parts included as shown.

Buckets and other components removed for clarity.